

Installation guidance

Thistle® Bond-it

Roller application

Step 1



Prepare the surface by cleaning to ensure it is dust free

Step 2



Stir by hand or with a mechanical whisk as contents may settle in storage. Do not dilute

Step 3



Apply to the background with a short pile roller or brush, using only one coat of Thistle Bond-it

Protect adjacent surfaces from splashes and remove any spillage immediately

Step 4



Allow Thistle Bond-it to dry fully before applying plaster

Note:

Thistle Bond-it should not be used with Thistle HardWall or Thistle DriCoat.

Ensure that the product is suitable for the background eg;

- Low suction backgrounds
- Cast concrete
- Painted and glazed surfaces
- MR grade plasterboards

Times and processes are given as guidance. On site practice may vary.